

series d-Drive® - DIGITAL PIEZO CONTROLLER

Interface- and display module EDS 1 and EDS 2

The data interface modules EDS 1 and EDS 2 enable communication between the user and the piezo system. The EDS 2 (part.no. E-751-000) comes with a VGA display. The cursor buttons navigate through the menus. By pressing the *Enter* button one can jump into the pertaining menu. The highlighted value can be changed by pressing the button. The value is entered by pressing the *select knob*. The old value is restored by leaving the menu without acknowledging it. The display shows status messages as well as recent values of the system. For full control and comfortable adjustment we recommend using a PC or laptop running d-Drive control program. The modules EDS are an integral part of the 19"-casing with a wide power range supply module from 110V up to 230V. The width of the casing is 84TE.

As opposed to the EDS2 the EDS1 offers an interface only. It has no display or controls. All adjustments have to be done by using a PC or laptop running the terminal program.



Display module EDS

technical data

E-750-000 **84TE width casing with EDS 1**
E-751-000 **84TE width casing with EDS 2**

	EDS 1	EDS 2
Part. no.	E-750-000	E-751-000
Display	no	QVGA LCD Display
Interface	RS 232; USB	RS 232, USB
Number of mountable controllers EVD 50	1...6	1...6
Menu	no	yes
Module width	24TE	24TE
Casing size	84TE	84TE
Main supply module	110V – 230V	110V – 230V