

## PZ 10

### compact z - axis translation stage

#### **Concept:**

The PZ 10 piezo electrical geared stage offers a vertical stroke of up to  $10\mu m.$  As a result of the solid state phenomena the resolution is practically unlimited down to the sub-nm range. The FEA designed actuating system based on flexure hinges guarantees excellent guidance accuracy without parasitic motion. The durability of the PZ 10 stages makes it an excellent choice for permanent use in industrial applications



Image: PZ 10

#### **Specials:**

Main advantages of the PZ 10 stage are shown in dynamical applications as well in static. The stage design allows a usage in application with off center loads. special features are maximum of stiffness in stroke direction and transverse to the stroke, combined with a high load capacity and robustness against lateral mishandling. Due to the excellent static properties the dynamical behavior shows a proper frequency spectrum considering resonances in the upper level. The sophisticated guidance design suppresses almost all lateral motion components with lateral runout of only a few nm. In addition the superior guidance accuracy shows only a few µrad rotational errors for all axes. All these features exhibit a very coast effective solution for high load applications. Vacuum and cryogenic designs are available on demand as well, body material variations of invar, superinvar, aluminum or titanium too.

#### **Product highlights:**

- motion up to 10 μm
- easy adjustment
- nm-resolution
- integrated preload
- dynamic application
- high resonant frequency
- combinable with other systems
- vacuum compatible

#### **Applications**

- fiber positioning
- laser optics
- scanning systems
- micro manipulation



Tel: +49 (3641) 66880 • Fax: +49 (3641) 668866 info@piezojena.com • http://www.piezosystem.com



# PZ 10

#### **Technical data:**

PZ 10		Unit	Part No. T-102-70
Axes		-	Z
motion open loop (±20%)	*	μm	10
resolution open loop		nm	0.02
capacitance (±20%)**		μF	3.6
voltage range		V	-20 thru +130
blocking force		N	3500
max. push/pull force		N	3500/350
stiffness		N/µm	350
resonant frequency	0g	kHz	5.0
	50g	kHz	4.5
	100g	kHz	4.0
	300g	kHz	3.0
rotational error	roll (x)	μrad	5.0
	pitch (y)	μrad	5.0
	yaw (z)	μrad	5.0
cable length		m	1.0
Connector		-	LEMO
Dimensions	length	mm	36.5
	width	mm	36.5
	height	mm	15.0
Weight		g	110
Material		- -	stainless steel

 $<sup>^{*}</sup>$  measured with NV 40/3

Specifications subject to change without notice!



Tel: +49 (3641) 66880 • Fax: +49 (3641) 668866 <u>info@piezojena.com</u> • http://www.piezosystem.com

<sup>\*\*</sup> typical small signal strength behavior